

Verlegehinweise

Laying instructions

(1) Bohrlöcher anzeichnen

Pro Sockelleiste sind 6 Clipse beigeigepackt. Verlegabstand von ca. 40 cm beachten. Bohrlöcher anzeichnen.

(2) Löcher bohren

Löcher mit 5 mm Ø bohren.

(3) Kunststoff-Clip befestigen

Kunststoff-Clip an der Wand verschrauben. Die vertikalen Langlöcher ermöglichen eine nachträgliche Höhenkorrektur. Nach der Verschraubung liegt der untere Steg der Clipse auf dem Belag auf. Geeignet für eine Fugenabdeckbreite von 22 mm.

(4) Kabel verlegen

Kabel können jetzt in den Halterungen verlegt werden.

(5) Oberprofil befestigen

Oberprofil aufclippen und fest einrasten.

(1) Mark drill holes

6 clips are included per baseboard. Follow a laying interval of about 40 cm. Mark drill holes.

(2) Drill holes

Drill holes with 5 mm Ø.

(3) Attach plastic clip

Screw plastic clip to the wall. The vertical slots allow for subsequent height correction. After screwing, the lower part of the clip is located on the flooring. Ideal for expansion joint widths of 22 mm.

(4) Lay cable

Lay cables in the clips.

(5) Fasten upper profile

Clip and link upper profile.

